



- NOTES:
1. MAT'L = 1/16" G10 FR4, 1 OZ. CU. 2
 2. FINISH;
CIRCUIT = TIN/LEAD ELECTRO-PL.
FINGERS = GOLD OVER NICKEL
 3. CHAMFER FINGERS 0.015 x 45°
 4. BREAK ALL SHARP CORNERS.
 5. APPLY SOLDER MASK TO BOTH S
 6. APPLY COMPONENT SILKSCREEN
SIDE AFTER SOLDER MASK.
USE WHITE EPOXY PAINT.

| HOLE CHART | | |
|------------|-------|-----|
| CODE | SIZE | QTY |
| UNMK'D | 0.031 | A/R |
| A | 0.040 | 116 |
| B | 0.144 | 4 |
| | | |
| | | |

HOLE SIZE GIVEN TO BE
±0.003 AFTER PLATE THRU